

Alice GTX 20 TX – Pinouts

GTX20 – FM Transmitter Connections

Pin	Function
1	SCA/RDS input
....9	Ground
2	Ground
....10	Left input hot
3	Pilot out (15V squarewave at 19kHz)
....11	Left input cold
4	Ground
....12	Left input ground
5	Remote shutdown (apply 5-20Vdc to shutdown)
....13	Right input hot
6	VSWR fault (active-on open-collector output, rated a 30V)
....14	Right input cold
7	Overtemp alarm (+15V active-high output)
....15	Right input ground
8	Out of lock (+15V active-high output)



Alice®